

# Technical Service Bulletin 113

## Membrane Cleaning

To maintain the performance and efficiency of LG Chem elements, the membranes should be cleaned periodically according to LG Chem’s specifications and requirements. Chemical cleaning is helpful in removing contaminants that have accumulated on the membrane surface or in the feed channel either from normal operation or an unexpected increase in feed water fouling potential.

Operating data should be collected and normalized frequently as described in LG Chem TSB 111. Trends of normalized data are the best indicators for determining when a membrane cleaning is required. A membrane cleaning should be performed when one or more of the following changes have occurred:

- Normalized permeate flow has decreased 10% since startup or last cleaning
- Normalized salt passage has increased 10% since startup or last cleaning
- Normalized pressure drop from feed to concentrate has increased 15% since startup or last cleaning.

Under certain conditions, cleanings may not be needed until changes greater than those listed above have occurred. Please contact LG Chem for possible site specific cleaning guidelines prior to any cleaning.

### Cleaning Chemicals

In many cases, RO elements can be effectively cleaned with a high pH sodium hydroxide solution (NaOH) followed by a low pH citric acid/HCl solution. The common chelating agent, EDTA, can be added to the sodium hydroxide solution if necessary. The recommended concentrations and allowable temperature and pH limits are provided below.

### Allowable pH / Temperature Limits

pH Limit	Corresponding Maximum Temperature (°C)	
	Seawater RO	Brackish Water RO
≥ 2	40	40
≤ 11	35	35
≤ 12	30	25

### Data Collection

It is important to collect the following data during the cleaning process:

Date & Time	Chemical(s) Used	Starting & Ending pH	Starting & Ending Temperature
Recirculation Flow & Time	Soak Time	Observations	

### CAUTION

*When using ANY chemical, follow accepted safety practices and read all manufacturer’s instructions. Consult the chemical manufacturer for further details on handling and disposal. When preparing cleaning solutions, ensure that all chemicals are dissolved and well mixed before circulation the solutions through the elements.*

#### Recommended Concentrations

Grade	Solution	Concentration	Recommended pH Range	Recommended Temperature Range (°C)
BW R BW ES BW UES	NaOH / RO permeate	Up to 0.1% by weight	10-12	25 - 30
	NaOH, EDTA / RO permeate	NaOH: Up to 0.1% by weight EDTA: Up to 1.0% by weight	10-12	25 - 30
	Citric Acid, HCl / RO Permeate	Citric Acid: Up to 2.0% by weight HCl: Up to 0.1-0.2% by weight	2-4	25 - 30
BW R G2 BW R Dura BW AFR G2	NaOH / RO permeate	Up to 0.1% by weight	11-13	25 - 30
	NaOH, EDTA / RO permeate	NaOH: Up to 0.1% by weight EDTA: Up to 1.0% by weight	11-13	25 - 30
	Citric Acid, HCl / RO Permeate	Citric Acid: Up to 2.0% by weight HCl: Up to 0.1-0.2% by weight	1-3	25 - 30
SW R / R G2 SW GR / GR G2 SW SR / SR G2 SW ES	NaOH / RO permeate	Up to 0.1% by weight	11-13	25 - 30
	NaOH, EDTA / RO permeate	NaOH: Up to 0.1% by weight EDTA: Up to 1.0% by weight	11-13	25 - 30
	Citric Acid, HCl / RO Permeate	Citric Acid: Up to 2.0% by weight HCl: Up to 0.1-0.2% by weight	2-4	25 - 30

#### Notes:

- Cleaning LG SWRO membranes at pH 13 is generally not recommended. However if a more aggressive cleaning is required, please contact the LG Chem Tech Service Team before proceeding
- HCl can be used for making a low pH cleaning solution. Please keep in mind the HCl is a strong acid and it is easy to overshoot the pH well below the recommended limit. LG Chem recommends starting the low pH solution with citric acid and making final adjustments with HCl.
- Use of generic or proprietary chemical cleaners other than those listed above may be necessary or desired. Please contact LG Chem and/or the chemical provider to verify the cleaning chemical's compatibility with LG Chem membranes and for its use in many site specific applications.

### Cleaning Procedure

1. If the unit does not have an adequate amount of permeate flush at shutdown, flush all vessels with RO permeate until the feed-concentrate process water is completely displaced. RO permeate used for flushing and mixing of cleaning chemicals must be free of any chlorine or other oxidizing agent.
2. Prepare a high pH NaOH solution per the allowable pH and temperature guidelines.
3. Introduce cleaning solution at a rate of 75 liters per minute (20 gallons per minute) per 8-inch diameter vessel.
4. Do not allow any feed-concentrate process water displaced from the introduction of cleaning solution to enter the cleaning tank. If the initial volume of cleaning solution returning to the tank is extremely dirty, discard that as well.
5. Recirculate the cleaning solution at a rate of 151 liters per minute (40 gallons per minute) per 8-inch diameter vessel for a period of 45 minutes.
6. Allow solution to soak if it has been determined that an extended soak time is beneficial to the cleaning process. Extended soak times typically range from 1-12 hours.

**Notes:**

Soak times are usually established based on operator knowledge of previous results or a detailed foulant analysis.

7. Flush the high pH cleaning solution from the vessels using RO permeate until the flush water pH exiting the vessel is close to the flush water pH entering the vessel. (Be sure to have an adequate amount of RO permeate stored before cleaning is initiated). If a soak period was introduced, recirculation of cleaning solution may also be required prior to flushing.
8. Closely monitor the pH of the cleaning solution during the cleaning process and adjust the pH as needed.
9. Measure the temperature and flow of the cleaning solution during the start, middle and end of the recirculation periods.
10. Never allow the vessel pressure drop to exceed 4 bar (60 psi) during any point in the cleaning. This applies to each pressure vessel housing FIVE OR MORE elements. If vessels contain less than five elements, contact LG Chem for pressure limit guidelines.
11. Once the high pH solution has been rinsed from all pressure vessels and piping as described in Step 7, proceed with a low pH cleaning using citric acid. HCl or the combination of Citric Acid and HCl can be used for making the low pH cleaning solution. Follow the appropriate pH and temperature limits. Flows, recirculation time, and maximum differential pressure for the low pH cleaning are the same as the high pH cleaning.
12. Once the low pH cleaning is complete, flush the spent solution from the vessels using RO permeate until the flush water pH exiting the vessel is close to the flush water pH entering the vessel.
13. Cleaning chemicals may be present in the permeate after cleaning. Upon restart (post-cleaning), RO permeate should be directed to drain for a minimum of 10 minutes. Please note that the permeate conductivity is usually elevated after a cleaning and may take some time to stabilize.
14. Contact LG Chem with the RO operating data taken prior to and 48 hours after cleanings.

**Notes:**

Direction of cleaning flow through the pressure vessels must always be in the same direction as feed flow during normal operation. Cleaning equipment, supply piping and return piping MUST be free of any contaminants or free standing water before beginning the cleaning process

The information and data contained herein are deemed to be accurate and reliable and are offered in good faith, but without guarantee of performance. LG Chem assumes no liability for results obtained or damages incurred through the application of the information contained herein. Customer is responsible for determining whether the products and information presented are appropriate for the customer's use and for ensuring that customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Specifications subject to change without notice. NanoH2O is the Trademark of LG Chem. All rights reserved. © LG Chem, Ltd.

**Contact Us**

• America +1 424 218 4000 • Europe, Africa +39 366 57 55 474 • Middle East, Egypt +971 50 558 4168  
• Korea +82 2 3773 6619 • China +86 21 60872900 • India +91 9810013345 • South East Asia +82 2 3773 3013